

Κωδικός Πλαισίου	Περιγραφή Κωδικού
2928086	Bosch Cooker Ceramic HKR390050
2928175	Pitsos Cooker Ceramic PHC009150
2928183	Pitsos Cooker Enamel PHA009020
2928868	Bosch Cooker Ceramic HKR390020
2928965	Bosch Retractable Hood DEM66AC00
2928973	Bosch Hood Standard DUL63CC50
2973588	Pitsos Cooker Ceramic PHN039150
2973626	Pitsos Cooker Ceramic PHC009120
3035816	Pitsos Cooker Enamel PHA009090
3036049	Pitsos Hobs Ceramic CRE645S06
3036065	Pitsos Hobs Ceramic CRS645T06
3082377	Bosch Oven VBC5580S0
3082709	Pitsos Hobs Ceramic CRE611S06
3082865	Pitsos Hood Trailer 2MIB60T
3082873	Pitsos Hood Folding 2MIB60L
3101452	Pitsos Cooker Ceramic PHN039350
3129950	Pitsos Hood Chimney PTK6E65G
3131238	Neff Hood Ceiling I95CAQ6N0
3504050	Bosch Fridge freezers KGN49XIEA
3540146	Bosch Single Door Fridge KSV36AIEP
3544877	Pitsos Fridge freezers PKNB36NWE0
3545830	Pitsos Dishwasher DVS50X00
3551385	Pitsos Dishwasher DSS60I00
3551393	Pitsos Dishwasher DIS60I00
3551466	Neff Freezer 00004 GI1113FE0
3558967	Bosch Fridge freezers KGN36NWEA
3558991	Pitsos Fridge freezers PKNB36NLE0
3577503	Pitsos Dishwasher DSS60W00
3581721	Pitsos Fridge freezers PKNB39VLE2
3591352	Bosch Fridge freezers KGV36VLEAS
3592359	Bosch Fridge freezers KGN36VLED
3600009	Pitsos Fridge freezers PKNB36VIE3
3613372	Pitsos Oven PH10M40X1
3613380	Pitsos Oven PH00M00X1
3619729	Pitsos Fridge freezers PKNB39VWEA
3680916	Neff Vacuum Drawer N17XH10G0
3681092	Neff Hood Trailer D49ED52X1
3681106	Neff Hood Trailer D46ED52X1
3682757	Bosch Hood Trailer DFR097A52
3683257	Bosch Hood Trailer DFR067A52
3763757	Bosch 3 doors plus KFF96PIEP

3929140	Bosch Single Door Fridge KSV36VWEP
3929159	Bosch 3 doors plus KFN96VPEA
3946762	Bosch Fridge freezers KGN397ICT
3949699	Bosch Fridge freezers KGN397LEQ
3952835	Bosch Hobs Ceramic NKF645GA2E
3953939	Bosch Hobs Ceramic PKF645FP3E
3954773	Bosch Hobs Inductive PUE611BB5E
3971066	Pitsos Microwave Oven PG30W75X2
3976335	Bosch Fridge freezers KGN39LBCF
3980170	Bosch Hobs Inductive PIE645BB5E
3983277	Bosch Hobs Ceramic PKE645BA2E
3996131	Bosch Hood Ceiling DRC99PS20
3996212	Bosch Fridge freezers KGN36NLEA
3996336	Bosch Freezer 00004 GIV11AFE0
4011007	Bosch Fridge freezers KGN367LDF
4015037	Neff Microwave Oven HLAWD23G0
4015509	Bosch side by side KFN96AXEA multi door
4022823	Neff Wine Cooler KU9213HG0
4036646	Pitsos Hobs Ceramic CRS631T06
4036778	Pitsos Hobs Inductive CWP631T12
4044487	Bosch Fridge freezers KGN56XIER
4044509	Pitsos Fridge freezers PKNB56XWEP
4045513	Pitsos Fridge freezers PKNB56XLEP
4045734	Pitsos Fridge freezers PKNB56XIDQ
4060490	Bosch Fridge freezers KGN497ICT
4067088	Bosch Fridge freezers KGN86VIEA
4076931	Bosch Fridge freezers KGN49LBCF
4077792	Pitsos Hood Trailer 2MID60T
4090357	Bosch Single Door Fridge KIR41VFE0
4097793	Bosch Washer-Dryer WNA144V9GR
4098080	Bosch Washing Machine WIW28542EU
4121295	Pitsos Fridge freezers PKNB39VIDT
4132769	Neff Fridge freezers KI7863DD0
4133056	Bosch Washing Machine WUU28T08GR
4134923	Bosch Fridge freezers KIN86ADD0
4159071	Neff Hood Chimney D94BHM1S5
4159179	Bosch Hobs Ceramic PKE61RBA2E
4182456	Bosch Fridge freezers KGN76XIEP
4206037	Bosch Freezer Column GSN36VWEP
4236289	Bosch Washing Machine WGB24409GR
4259440	Bosch Tumble Dryer WQB245B8GR
4259467	Pitsos Washer-Dryer WDP14C09GR
4268229	Bosch Hobs Inductive PXY875KW1E
4270401	Bosch Microwave Oven FEL023MS2
4288556	Bosch Side by Side KAD93AIEP

4288726	Bosch Fridge freezers KGN39VIBT
4302931	Neff Hobs Inductive T46SBE1L0
4318218	Pitsos Dishwasher DVF60X01
4318226	Pitsos Dishwasher DSF60W01
4318404	Pitsos Hood Chimney PTI8E66G
4320352	Neff Hobs Ceramic T18FDH9L
4320387	Neff Hobs Inductive T56FHS1L0
4329554	Neff Hobs Inductive T56STF1L0
4329589	Bosch Dishwasher SPV4HKX10E
4331354	Pitsos Dishwasher DSF60I01
4352580	Neff Hobs Ceramic T16SBF1L0
4356438	Pitsos Dishwasher DVS61X01
4367049	Pitsos Dishwasher DIS61I01
4368150	Pitsos Dishwasher DIF60I01
4368630	Pitsos PH10M40X1 + CRE645S06
4370279	Neff Microwave Oven NL9GR31Y1
4370295	Neff Microwave Oven NR9GR31Y1
4370368	Neff Oven C29FS3AY0
4370376	Neff Oven C29MR21Y0
4370384	Neff Oven B69FY5CY0
4370392	Neff Oven B69VY7MY0
4370406	Neff Hobs Domino T63TDX1L0
4370422	Bosch Fridge freezers KBN96VFE0
4370430	Neff Oven B69CS7MY0
4370449	Bosch Fridge freezers KIN96VFD0
4370457	Neff Oven B59CR7KY0
4370473	Neff Fridge freezers KB7966DD0
4370481	Neff Oven B29CR7KY0
4370503	Neff Oven B59CR31Y0
4370511	Neff Oven B29CR3AY0
4370538	Bosch Fridge freezers KGN76AXDR
4370783	Bosch Wine Cooler KWK16ABGB
4370791	Neff Single Door Fridge KI1813DD0
4370805	Neff Hobs Inductive T69YYV4C0
4370813	Neff Hobs Inductive T68YYY4C0
4370821	Neff Hobs Inductive T66YYY4C0
4370864	Bosch Dishwasher SPS4EMI10E
4371232	Neff Hood Downdraft I98WMM1Y7
4371267	Bosch Washer-Dryer WKD28543EU
4374347	Bosch Dishwasher SPS2HKI58E
4380509	Neff Warming Drawer N29HA11Y1
4381424	Bosch Dishwasher SMS4HTW00E
4381505	Neff Hobs Domino T13TDF9L8
4385691	Bosch Dishwasher SPS2HKW58E
4388542	Neff Freezer 00004 GI7813CE0

4388550	Bosch Dishwasher SMS4ENI06E
4388593	Bosch Dishwasher SMS4ECI26E
4407210	Neff Hobs with hood V68YYX4C0
4409280	Neff Hood Chimney D98IPT2Y5
4410319	Bosch Dishwasher SPI4HMS49E
4411889	Neff Oven L2ACH7MG0
4412877	Bosch Hood Trailer DFR067T51
4413326	Neff Hood Chimney D65IFN1S0
4413334	Neff Hood Chimney D88IAN2S0
4413342	Bosch Hood Chimney DWK81AN60
4413350	Pitsos Hood Chimney PTI6E66G
4416244	Bosch Fridge freezers KGN492XCF
4416341	Bosch Oven HSG7584B1
4416384	Bosch Oven HMG776KB1
4418417	Bosch Oven HRG7761B1
4418646	Bosch Oven HBG7764B1
4418883	Bosch Oven HBG7721B1
4418948	Bosch Oven HBG7541B1
4418956	Bosch Oven HBG7321W1
4418964	Bosch Oven HBG7241B1
4418972	Bosch Microwave Oven BEL7321B1
4418999	Bosch Oven CMG7241B1
4419057	Bosch Built in Coffee Machine CTL7181B0
4419243	Bosch Single Door Fridge KUR21VFE0
4420551	Bosch Washing Machine WGG244FGGR
4424700	Bosch Cooker Ceramic HKR39A250U
4455398	Bosch Fridge freezers KGN33NWEB
4455401	Bosch Fridge freezers KGN33NLEB
4455932	Bosch Cooker Ceramic HKS79U250
4456386	Bosch Cooker Ceramic HKS59E150U
4475852	Bosch Washing Machine WUU28T02GR
4476336	Neff Freezer 00004 GU7213DE0
4479858	Bosch Washing Machine WGG244ZHGR
4483359	Neff Built in Coffee Machine CL9TX11Y0
4502604	Bosch Washing Machine WGG244ZXGR
4503074	Bosch Fridge freezers KGN392XCF
4503805	Bosch Fridge freezers KGN392LCF
4504151	Bosch Washing Machine WGG244ZBGR
4504186	Bosch Washer-Dryer WNA14411GR
4504194	Bosch Washer-Dryer WNC254A0GR
4504607	Bosch Hobs with hood PVQ811H26E
4506367	Bosch Washing Machine WUU28TX2GR
4506375	Bosch Fridge freezers KGN394ICF
4545958	Bosch 3 doors plus KMC85LBEA
4546164	Bosch 3 doors plus KFD96APEA

4546253	Bosch Hood Chimney DWK67FN60
4546261	Bosch Hobs with hood PVS611B16E
4546466	Bosch Hood Island DIB97IM50
4546733	Pitsos Washing Machine WUP140BG9
4546776	Bosch Washing Machine WAN282P8GR
4546784	Pitsos Washing Machine WUP140ZG9
4570162	Neff Warming Drawer N29HA11Y2
4570286	Neff Hobs Inductive T36FBE1L0
4582217	Bosch Washing Machine WGE03400GR
4589785	Pitsos Washer-Dryer WDP1400G11
4615239	Bosch Washing Machine WGE02400GR
4615247	Pitsos Washing Machine WF4J06L8
4615395	Neff Oven B24CR71G0
4644948	Bosch Washing Machine WGG244ZREU
4667433	Bosch Oven HBF154BS0
4669495	Bosch Oven HBA272BB3
4669649	Bosch HBF154BS0 + PKE645BA2E
4671686	Bosch Microwave Oven BFL520MS0
4675487	Pitsos Tumble Dryer WTP704D8
4676718	Bosch Washing Machine WGB254A1GR
4677242	Bosch Oven HBA514BB3
4677889	Neff Oven B1ACC2AN3
4677900	Neff Oven B5ACH7AG3
4678346	Neff Oven B1ACE4AG3
4678354	Pitsos Oven PH38M21B3
4681096	Bosch Oven HBA514BS3
4681444	Bosch Oven HBA534ES4
4684206	Pitsos Oven PH27M61X3
4690540	Bosch Dishwasher SMI6ZCS10E
4690567	Bosch Dishwasher SMV4HTX00E
4690575	Neff Dishwasher S155EAX16E
4690583	Bosch Dishwasher SMI4ECS28E
4696719	Bosch Washing Machine WGB25411GR
4696786	Neff Microwave Oven HLAWD23N1F
4711084	Bosch Dishwasher SMI4HTS00E
4716582	Pitsos Cooker Gas PAF003D20
4725964	Bosch Dishwasher SMV4EVX04E
4725972	Bosch Dishwasher SMI4EVS04E
4725980	Bosch Dishwasher SMS4HMW07E
4760115	Pitsos Tumble Dryer WT231G39
4760964	Bosch Tumble Dryer WTH85208GR
4776038	Neff Oven U1ACE2AG3B
4776089	Bosch Hobs Gas PNK6B6K40
4778790	Bosch Washing Machine WGG254ZNGR
4796829	Bosch HBA272BB3 + PUE611BB5E

4809793	Bosch Washing Machine WGG254ZHGR
4821653	Pitsos Washing Machine WF4J06L7
4822862	Pitsos PH33M40B3 + CRE611S06
4824237	Bosch Tumble Dryer WQG24201GR
4827171	Bosch Hood Built-in canopy DLN56AC60
4827198	Bosch Dishwasher SMS6ECI15E
4831497	Neff Hobs Gas T26PIP4S0
4835867	Pitsos Washing Machine WPG140HZ0
4835875	Pitsos Washing Machine WPG140LZ0
4838513	Bosch Fridge freezers KGN493IDA
4838521	Bosch Fridge freezers KGN39VIDB
4843665	Bosch Fridge freezers KGN39VIEB
4843673	Bosch Fridge freezers KGN39OCAF
4843681	Bosch Fridge freezers KGN49OCAF
4845072	Bosch Hobs Inductive PVS631HC1E
4845080	Bosch Hobs Inductive PVW831HC1E
4845099	Bosch Oven HBA574BS3
4847326	Bosch Tumble Dryer WTH83208GR
4872983	Bosch Freezer Column GSN36VIEP
4873009	Bosch Single Door Fridge KSV36CIDP
4874587	Bosch Washing Machine WGG254F2GR
4874595	Bosch 3 doors plus KFI96AXEA
4874609	Bosch Hobs Gas POP6B6K30
4874714	Neff Hobs Gas T27PIQ4S0
4874722	Neff Hobs Gas T26CIP8N0
4874730	Neff Hobs Hobs with Extractor V68YYX4B0
4889584	Neff Fridge freezers KI7962FD0
4889967	Bosch Tumble Dryer WQG243B9GR
4891694	Pitsos Fridge freezers PKNB49XIDP
4903307	Pitsos Oven PH12M41B0
4908015	Neff Oven B2ACJ7AG0
4909984	Pitsos Oven PH22S40X3
4914694	Bosch Tumble Dryer WRB247D0GR
4954815	Bosch Tumble Dryer WQG245DREU
4954904	Bosch Oven HEG537BS4
4963717	Bosch Oven HBA534BW3
4974077	Bosch Dishwasher SMS4HVC11E
4978552	Bosch Washing Machine WGB24459GR
4979966	Bosch Oven HBA572BB4
4979974	Pitsos Oven PH10M40X2
4995937	Neff Dishwasher S175HCX03E
4995945	Bosch Dishwasher SMH4HCX07E
5005264	Pitsos Oven PH33M40B4
5005272	Bosch Dishwasher SMI4HVS14E
5009200	Bosch Dishwasher SMS4HTI16E

5015162	Bosch Dishwasher SMV4HVX14E
5015189	Bosch Dishwasher SPI4EMS17E
5015413	Pitsos Oven PH33M41B4
5017831	Pitsos Tumble Dryer WT232G09
5023890	Pitsos Dishwasher DVF61X02
5024439	Bosch Dishwasher SPI6EMS21E
5071372	Neff Hood Chimney D65BCC2L0
5071380	Neff Hood Chimney D65BCC2S0
5071399	Neff Hood Chimney D67BDN2S0
5071402	Neff Hood Built-In D69XET2S5
5071410	Neff Hood Chimney D97BDN2S0
5071429	Neff Hood Built-In D99XET2S5
5071437	Bosch Hood Built-In DBB67DP60
5071445	Bosch Hood Built-in canopy DBB95CC60
5071453	Bosch Hood Built-in canopy DBB97DP60
5071461	Pitsos Dishwasher DIF61I02
5071488	Pitsos Dishwasher DSF61I02
5071496	Bosch Hood Chimney DWB65CC30
5071518	Bosch Hood Chimney DWB95CC30
5071526	Neff Hood Island I95BBE2N0
5071534	Pitsos Hood Built-In PID6D76G
5071542	Pitsos Hood Chimney PTK6D73G
5071550	Bosch Hobs with hood PVQ711H26E
5071569	Neff Dishwasher S177ZCX18E
5071577	Neff Dishwasher S197YCX07E
5071585	Neff Dishwasher S855EMX34E
5071593	Neff Dishwasher S875EMX35E
5071607	Bosch Dishwasher SMD6ECX21E
5071615	Bosch Dishwasher SMP4ECC72S
5071623	Bosch Dishwasher SPS6EMI21E
5071631	Bosch Dishwasher SPV4EKX17E
5071658	Bosch Dishwasher SPV6EMX09E
5071666	Neff Hobs with hood V56FHQ4L0
5102707	Bosch Hood Chimney DWB97DN60
5102715	Bosch Hood Chimney DWB65CC60
5102723	Bosch Hood Chimney DWB95CC60
5102731	Bosch Hood Chimney DWB97DN30
5102758	Bosch Hood Chimney DWB67DN30
5102766	Pitsos Hobs Ceramic CRD645T06
5102774	Bosch Hobs Ceramic PKN645FP2E
5102782	Neff Hobs Ceramic T16FTN1L0
5102790	Neff Hobs Inductive T56NUQ4A0
5116279	Bosch Washer-Dryer WKD28490EU
5116376	Pitsos Washing Machine WPG140KF0
5116384	Bosch Washing Machine WAN2828HGR

5116392	Bosch Washing Machine WGB264A0GR
5153360	Neff Hobs T18SDH9L0
5153379	Bosch Hobs PXY63KHC1E
5153387	Bosch Hobs PXY83KHC1E
5153395	Bosch Dish SPI2HKS02E
5153409	Bosch Dish SMS4HMW08E
5153417	Bosch Dish SPS2HKI55E
5153425	Bosch HQA574BB3 Oven
5153433	Neff B59CR3AY0 Oven
5153441	Bosch Dish SMH6ZCX24E
5153468	Bosch Hobs PVS63KBB5E
5153476	Neff Hobs T68NUV4A0
5153484	Neff Hobs T66YYY4B0
5153492	Neff Hoods D5655X2
5153506	Bosch Hoods D5655X2